Text Messaging

Your radio can receive a text messages, either from another radio or an e-mail application.

Using Text Message Features

- 1. Press Menu to access the menu.
- 2. Use the arrow keys to see Messages and press OK to select.
- 3. Use the **arrow** keys to see Write and press OK to select.
- 4. Use the keypad to type your message.
- 5. Press **OK** once the message is composed.
- 6. Use the **arrow** keys to see Send and press OK to send the message.
- 7. If the message is sent, a tone sounds and the display shows *Message Sent*.

Making Changes to Radio Service

Log into **MyServices** at *myservices.missouri.edu* to submit a Change Request. You will need the four-digit MU number from the radio(s).

Using Text Message Features

You can use the alphanumeric Keypad to type messages. Many characters require that you press a key multiple times. The table below shows the number of times a key needs to be pressed to generate the required character.

Keypad Controls

Key	Number of Times Key is Pressed												
	1	2	3	4	5	6	7	8	9	10	11	12	13
12	1		,	?	1	@	&	1	%	-	:	•	#
2.4x	А	в	С	2									
3.0	D	Е	F	3									
4 (6)	G	н	1	4									
5 🕫	J	к	L	5									
6	м	Ν	0	6									
7 1*#	Р	Q	R	S	7								
8.000	т	U	V	8									
9 0007	w	х	Y	Z	9								
0.00	0	NOTE: Press to enter "0" and long press to activate the CAPS lock. Another long press to turn off the CAPS lock.											
* (*)	* or del	NOTE: Press during text entry to delete the character. Press during numeric entry to enter a ***.											
#	# or space	NOTE: Press during text entry to insert a space. Press during numeric entry to enter a "#".											





Mototrbo[™] XPR 6580

More than just push-to-talk radio.

The MOTOTRBO radio integrates voice and data into one device. Text messaging allows users to share information when voice communication is not practical. Users can communicate between radios, radios and dispatch systems, and radios to email-capable devices.

Radio Controls





Basic Radio Operations

- 1. Rotate the **On/Off/Volume** control knob clockwise to turn the radio on or off or adjust the volume.
- 2. Press and hold the **Push-to-Talk (PTT)** button on the side of the radio to talk. Release to listen.
- 3. To initiate a scan, press the blue button on the side of the radio to Scan or select **SCAN** in the menu.

Contacts for your group have been preprogrammed into your radio. Each entry corresponds to an alias or ID that you use to initiate a call.

Making Radio Calls

Your Motobro radio can make and receive private or system-wide calls. Select a **Site, Zone** and **Radio Channel** or **Subscriber ID** or **Group ID**.

Group Call/All Call

To receive and respond to a Group Call /All Call your radio must be configured as part of that group.

- 1. Turn the Channel Selector Knob to select the channel with the active group alias or ID. The LED indicator *blinks* green.
- 2. Hold the radio 1 to 2 inches from your mouth.
- 3. Press the PTT button to make the call. The LED indicator shows solid green.
- 4. Wait for the tone to finish (if enabled) and speak clearly into the microphone.
- 5. Release the **PTT** button to listen.
- 6. When the target radio responds, the LED blinks green.

Private Call

A Private Call is from an individual radio to another individual radio. Your radio must be programmed to initiate a Private Call.

- 1. Use the Call Alert features to contact an individual radio.
- 2. Turn the Channel Selector Knob to select the channel with the active subscriber alias or ID.
- 3. Hold the radio 1 to 2 inches from your mouth.
- 4. Press the **PTT** button to make or respond to the call. The LED indicator shows solid green.
- 5. Wait for the tone to finish (if enabled) and speak clearly into the microphone.
- 6. Release the **PTT** button to listen. When the target radio responds, the LED blinks green.